

Flame Effect

Press to turn the flame effect, media, and overhead lights on or off.

Temperature Decrease

Flame Speed

Moods

8 different Moods, are different combinations of overhead and media bed lighting.

Flame Theme

Timer

Press repeatedly until the desired number of hours is displayed.

Standby ON/OFF

Heat ON/OFF

Temperature Increase

Heat Mode

Brightness

Press repeatedly to cycle through the brightness and flicker modes.

Ambient Light Sensor

Auto adjusts the brightness of the fireplace lights based on the light condition in the room.



**FOR MORE DETAILED REMOTE FEATURES
SEE INSTALLATION AND USERS GUIDE.**

Effet de flamme

Appuyer sur pour activer ou désactiver l'effet de flamme, le lit de braise et l'éclairage supérieur.

Diminution de la température

Vitesse de la flamme

Ambiances

Huit différentes Ambiances, qui sont différentes combinaisons d'éclairage supérieur et du lit de braises.

Style de flamme

Minuterie

Appuyez plusieurs fois sur la touche jusqu'à ce que le nombre d'heures souhaité s'affiche.

Veille

Chauffage

Augmentation de la température

Mode de chauffage

Luminosité

Appuyer plusieurs fois sur pour alterner entre les modes de luminosité et de scintillement.

Capteur de lumière ambiante

Le capteur de lumière ambiante ajuste automatiquement la luminosité du foyer en fonction de la lumière ambiante dans la pièce.



**POUR PLUS DE DÉTAILS SUR LES PROCÉDURES À DISTANCE
VOIR LE GUIDE D'INSTALLATION ET D'UTILISATION.**